

## SECTION 7 –USER INFORMATION AND PRODUCT MARKING



### USER INFORMATION

**Product reference:** Slim Fit Gloves      **Glove sizes available:** 5,6,7,8

**Manufacturer:**

Le Mark Group Ltd  
Unit 1 Houghton Hill Industries  
Sawtry Way  
Houghton, Huntingdon  
Cambridgeshire  
PE28 2DH  
United Kingdom

**Notified Body responsible for certification:**

SATRA Technology Europe Ltd  
Bracetown Business Park  
Clonee  
Co. Meath  
D15 YN2P  
Ireland

**Glove Designation**

These gloves are designed to protect the palm of the hands against minor abrasions and injuries which may come as a result of handling rigging equipment.

*These Gloves are classed as Personal Protective Equipment (PPE) by the European PPE Regulation (EU) 2016/425 and have been shown to comply with this Regulation through the Harmonized European Standard(s) EN388:2016 EN 420: 2003 + A1: 2009*

**Performance and limitation of use**

This product has been tested in accordance with EN388:2016 EN 420:2003+A1:2009

Do not use near machinery or moving parts (entanglement hazard)

Gloves do not protect against thermal or chemical hazards

Gloves should not be used to protect against cut hazards or sharp edges

Inspect gloves for damage and imperfections before use, do not use damaged gloves

Information regarding protection refers to the working surface, i.e. 'the palm' of the glove, which has been submitted to testing.

The protection levels indicated are only valid for new gloves.

Keep away from fire.

**Storage**

When not in use, store the product in a well-ventilated area away from damp

Keep out of direct sunlight, in a cool dry place

**Cleaning and Maintenance**

These gloves should not be washed, laundered or ironed

New and used gloves should be thoroughly inspected for damage before use.

**EU Declaration of conformity can be accessed at:** [www.dirtyrigger.co.uk/guides/](http://www.dirtyrigger.co.uk/guides/)

**Substances Contained in Gloves that could cause Allergies:**

*Gloves contain latex – May cause allergic reactions. In case of hypersensitivity seek medical advice.*

