INSTRUCTIONS FOR USE

EN 12477 WELDING GLOVES

Australia Ansell Lim

EN 12477 WELDING GLOVES

Ansell Limited Level 3, 678 Victoria Street Richmond VIC 3121

Australia

North America Region

Ansell Protective Products Inc. 111 Wood Avenue South Suite 210

Iselin NJ 08830 United States

Europe, Middle East and Africa (EMEA) Region

Ansell Healthcare Europe N.V. Riverside Business Park Boulevard International, 55

1070 Brussels Belgium

Latin America and Caribbean Region

Ansell Brazil Ltda Rua das Figueiras 474 – 4° Andar Bairro Jardim SP 09080–300 Santo André Brazil CNPI: 03.496.778/0001–21

☎ +5511 3356 3100

.

Asia Pacific Region
Ansell Global Trading Center
(Malaysia) Sdn Bhd, Prima 6, Prima Avenue,
Block 3512, Jalan Teknokrat 6, 63000
Cyberjaya, Selangor, Malaysia
7 +60 3 8310 6688

Russia

Анселл РУС Краснопресненская, Наб. 12, п. 3, оф. 1304-A 123610 Москва, Россия **Т** + 7495 758 13 16

www.ansell.com

A. Use

This Instruction for Use note is to be used in combination with the specific information that is mentioned inside each packaging enclosure.

These gloves are designed to protect the hands and/or forearms against mainly mechanical and/or thermal risks. They are in conformity with, and are marked per the requirements, of the European Directive 89/686/EEC and its amendments. They also comply with the applicable European Standards. Please ensure the gloves are used only for the designated purposes.

Explanation of pictograms and relevant complying standards :



Protection from mechanical risks A: Abrasion resistance B: Cut resistance C: Tear resistance D: Puncture resistance



B: Contact heat C: Convective heat D: Radiant heat E: Small splashes of molten metal F: Large quantities of molten metal

EN 12477 A = Protective gloves used in higher-heat welding applications, including Stick and MIG welding.

EN 12477 B = Protective gloves used in lower-heat welding application that require high dexterity, including TIG welding.

EC-Type examination certificate from Centexbel Belgium (I.D. 0493),

Technologiepark 7, B-9052 Zwijnaarde.

For more detailed information on the product's performance and to obtain a copy of the Conformity Declaration, please consult Ansell.

B. Precautions for use

- 1. NEVER USE THESE GLOVES WITH CHEMICALS.
- 2. The gloves should not be used when there is a risk of entanglement with moving machine parts.
- 3. Before usage, inspect the gloves for any defects or imperfections. Avoid wearing damaged, dirty or worn out gloves.
- 4. The gloves should not come in contact with a naked flame.
- 5. The glove does not normally allow penetration of UV radiation. There is no standardised test method for detecting UV penetration.
- 6. When gloves are being used for Arc welding, they should not be used to protect against electric shock. The electrical resistance of the glove is reduced if gloves get wet.

C, Ingredients / Hazardous ingredients

Gloves might contain ingredients which are known to be a possible cause of allergies in sensitised persons, who may develop irritant and/or allergic contact reactions. If allergic reactions should occur, obtain medical advice immediately.

For more information, please contact Ansell's Technical department.

D. Care instructions

Storage: Keep away from direct sunlight; store in a cool dry place.

Keep away from ozone sources or naked flame.

Cleaning: Gloves are not designed to be laundered, unless specifically stated in the information added inside each packaging enclosure.

E. Disposal

Used gloves may be contaminated with infectious or other hazardous materials.

Dispose of according to Local Authority Regulations. Landfill or incinerate under controlled conditions.



